

## SUPPLEMENTARY MANUAL

for GPDS-HO1

REMOVE THE PASSANGER SEAT.



REMOVE THE MAIN SEAT.



REMOVE THE LEFT AND RIGHT
BLACK FRAME COVERS
BELOW THE MAIN SEAT AND
FUEL TANK.
LIFT UP OR REMOVE THE
FUEL TANK.





## CONNECT DS-SERIES CONNECTOR

## DIAGNOSTIC SYSTEM CONNECTOR.

(RED, 4-POLE CONNECTOR WITH RED CAP
UNDER BLACK AND WHITE CONNECTORS
AT THE RIGHT SIDE)



TYPICAL POSITION FOR THE GEAR INDICATOR.

